

Guidelines for Defining the Basic Analysis Parameters

The IncuCyte® Basic Analysis software allows for the quantification of phase and fluorescent object metrics in real-time. The Basic analyzer enables you to tailor phase segmentation parameters to individual cell types and experimental conditions, to accurately distinguish between background and positive fluorescent objects across a wide range of intensities, and allows for the quantification of overlap between green and red fluorescent objects within each image.

This guideline covers the following topics for defining basic analysis parameters:

- [Defining the Analysis Parameters for the Phase Image Channel](#)
- [Defining the Analysis Parameters for the Green and Red Image Channels](#)
- [Coincident object analysis](#)

The following procedures are for example purposes only and are designed to provide a frame of reference for defining the Basic Analysis Parameters (step 5) within the Analysis Wizard.

Defining the Analysis Parameters for the Phase Image Channel

The following section will guide you through refining the analysis definition in order to accurately mask phase images of your experimental conditions (e.g., cell type, assay conditions, and magnification).

1. In the Object name field, enter the name of the object that is being analyzed. [See Figure 1](#)




For easier identification of the analysis definition, you might want to name the object the same as the cell type that was used in the assay, for example, HT-1080.

2. Click Preview Current or All. [See Figure 1](#)



The best way to begin setting up the Analysis Definition is to use the preset values already contained within the Analysis Definition Editor, therefore do not change Segmentation Adjustment, Cleanup, or Filters at this time.

Figure 1. Basic Analyzer Image Preview (phase only)



3. Evaluate your Confluence Mask (which is the mask applied to the phase channel) and refine the parameters accordingly. [See Figure 2 and Table 1](#)



Modify only a single analysis definition parameter at a time. After you define the value for a parameter, click Preview Current to apply and view the change for the image that is currently displayed in the Image pane.

Figure 2. Parameter Refinement with Confluence Mask




Table 1: Phase Image Channel Analysis Definition Options

Option	Description
Parameters	
Segmentation Adjustment	Read-only display that is dynamically updated to reflect the value to which you adjust the Background/Cells slider bar.
Background/Cells	Use the slider bar to adjust the mask to pick up a greater number of cells (move towards Cells) or reduce the image background (move towards Background).
Cleanup	
Hole Fill	Removes any holes in the mask that are smaller than the area that is specified.
Adjust Size	If set to a positive value, then enlarges the mask by the specified number of pixels. If set to a negative value, then shrinks the mask by the specified number of pixels.
Filters - Used to remove any background that is not a true mask.	
Area	Defines a range of sizes (in μm^2) for the object and eliminates objects that fall outside this range
Eccentricity	Defines a range of roundness for the object and eliminates objects that fall outside this range. Eccentricity ranges from 0 to 1 with a perfect circle having a value of 0.

- Once you have previewed all of the images within the wizard image set and are satisfied with the parameters, complete the Launch wizard analysis to select the Scan Times and image sites to be analyzed, as well as assigning an analysis definition name.

After the vessel images have been analyzed using phase object analysis, the following set of metrics are provided:

Phase Metric	Description
Confluence (%)	The percentage of the image area that is occupied by objects.
Count (1/image, 1/ mm^2 or 1/well)	The number of objects per image, mm^2 , or well.
Average Area (μm^2)	The average of the area of the objects in the image.
Average Eccentricity	The average of how round or compact the objects are. Ranges from 0 to 1 with a perfect circle having a value of 0.

Defining the Analysis Parameters for the Red and Green Image Channel

The following section will guide you through refining the analysis definition in order to accurately identify fluorescent objects across a wide range of intensities, in order to produce data that can kinetically measure apoptosis, cytotoxicity, proliferation of fluorescently-labeled cells and other cell biology applications.



Prior to creating a fluorescent analysis definition, if images were acquired in both the Green and Red channels, ensure that you have evaluated if spectral unmixing is required to removed signal from one of the given channels.



If dual fluorescent images were acquired, define the analysis parameters for one channel at a time using the expand and collapse arrows within the Analysis Definition Pane.


1. In the Object name field, enter the name of the object that is being analyzed. [See Figure 3](#)



For easier identification of the analysis definition, you might want to name the object the same as the reagent or phenotypic object that was used in the assay, for example, Caspase-3/7.

2. Define the segmentation analysis parameters to segment object. [See Table 2 and Figure 3](#)

Table 2: Fluorescent Analysis Methods

Option	Description
No Background Subtraction	
Adaptive	A local background level (LBL) across each processed image is automatically determined and the user inputs a Threshold Adjustment value this far above the LBL. It is advised to preview the default threshold adjustment of 2.0. To include more objects, lower this parameter, to exclude background, increase this parameter.
Fixed Threshold	A single threshold level in calibrated fluorescence units is used across the image. This number can be set as a number near or in between the dimmest positive object and the brightest background area.
Background Subtraction	
Top-Hat	Utilizing the radius of the largest fluorescent object, a background trend across the image is estimated and then subtracted. Objects that are brighter than the specified threshold value are detected in the background-subtracted image. Click the Measure image features icon  , and then drag your mouse pointer to measure the radius of the largest object in the selected image channel. The value is displayed in the lower right corner of the image. Enter this value for the Radius. See Figure 3



When using Top-Hat segmentation, note that a radius that is set too small may result in a loss in object detection. A radius that is set too large can cause incorrect background estimation.

Figure 3. Basic Analyzer Image Preview (fluorescent channels)



3. Click Preview Current or All. See Figure 3



The best way to begin setting up the Analysis Definition is to use the preset values already contained within the Analysis Definition Editor, therefore do not change “Segmentation Adjustment”, “Cleanup”, or “Filters” at this time.



If using Top-Hat segmentation, once the image is previewed, a background subtracted image is formed and displayed in a new tab under the available color channels. Use the “Original” and “Background Subtracted” tabs to compare between the two images. Only the “Background Subtracted” image will be used for segmentation. See Figure 4

4. Evaluate the fluorescent mask. See Figure 4


- Make sure that both the correct fluorescent image channel box and the Analysis Mask box are checked.
- Assess the Analysis Mask using the Blend or Overlay Mode. A Mask Outline, with slider to adjust the Outline Width, and Color selection options aid in evaluating the Analysis Mask. Changing these will not affect the analysis definition.



To assist you with viewing the effects of applying an analysis parameter, use the image navigation functions (zoom in, zoom out, home).

5. If necessary, adjust the segmentation by increasing the threshold to eliminate masking of background or by decreasing the threshold to include dimmer objects.

Figure 4. Parameter Refinement with Fluorescent Channel Mask



6. Click Preview Current or All.

7. Evaluate your fluorescent mask and refine the parameters accordingly. See Figure 4 and Table 3.

Table 3: Fluorescent Analysis Parameters

Option	Description
Edge Sensitivity	If Edge Split is turned on, then use the slider bar to adjust the Edge Sensitivity. The default value is 0. As you increase the Edge Sensitivity, the number of splits are also increased.
Cleanup	
Hole Fill	Removes any holes in the mask that are smaller than the area that is specified.
Adjust Size	Adjusts the size of your mask in pixels by either shrinking the mask (if negative) or growing the mask (if positive).
Filters – Used to remove any undesirable masked objects	
Area	Defines a range of sizes (in μm^2) for the object and eliminates objects that fall outside this range
Eccentricity	Defines a range of roundness for the object and eliminates objects that fall outside this range. Eccentricity ranges from 0 to 1 with a perfect circle having a value of 0.
Mean Intensity	Defines the limits of mean intensity of an object, (the average pixel intensity in calibrated units), and eliminates objects that fall outside this range.
Integrated Intensity	Defines the limits of integrated intensity of an object, (the summed pixel intensity in calibrated units), and eliminates objects that fall outside this range.

8. Once you have previewed all of the images within the wizard image set and are satisfied with the parameters, complete the Launch wizard analysis to select the Scan Times and image sites to be analyzed, as well as assigning an analysis definition name.

After the vessel images have been analyzed using fluorescent object analysis, the following set of metrics are provided:

Fluorescent Metric	Description
Object Count (1/image or 1/mm ² or 1/well)	The number of objects per image, per mm ² , or per well.
Avg. Area (μm ²)	The average area of the objects in the image.
Total Object Area (μm ² /Image or μm ² /Well):	The total amount of area within an image or a well containing fluorescent objects.
Confluence (%)	The percentage of the image area occupied by objects.
Avg. Mean Intensity (CU)	The image average of the objects' mean fluorescent intensity.
Avg. Integrated Intensity (CU x μm ²)	The image average of the objects' integrated fluorescent intensity.
Total Integrated Intensity (CU x μm ² /Image)	The total sum of the objects' fluorescent intensity in the image.
Avg. Eccentricity	The average of how round or compact the objects are. Ranges from 0 to 1 with a perfect circle having a value of 0.

Coincident Object Analysis

The following section will guide you through refining the analysis definition in order to accurately quantify the extent of the overlap between green and red fluorescent objects within each image.

1. Create a suitable mask for the green and red fluorescent objects (refer to Defining the Analysis Parameters for the Green and Red Image Channels)
2. In the Object name field, enter the name of the object that is being analyzed. [See Figure 5](#)




For easier identification of the analysis definition, you might want to name the object the same as the biology that is occurring in the assay, for example, T-cell contact.

3. Click Preview Current or All. [See Figure 5](#)
4. Evaluate the Overlap Mask and filter for size to eliminate small or large objects, if required.



The Overlap Mask does not take into account the intensities of the green or red fluorescent channels, it only quantifies the overlay of the masked areas (area or count).

Figure 5. Overlap Analysis within the Basic Analyzer



5. Once you have previewed all of the images within the wizard image set and are satisfied with the parameters, complete the Launch wizard analysis to select the Scan Times and image sites to be analyzed, as well as assigning an analysis definition name.

After the vessel images have been analyzed using coincident (overlap) analysis, the following set of metrics are provided:

Metric	Description
Count (1/image, 1/mm ² or 1/well)	The number of objects per image, mm ² , or well.
Average Area (μm ²)	The average of the area of the objects in the image.